User Manual
RKR-360

Compatible with Windows 2000 / Windows XP / Windows Vista / Windows 7.

Introduction

RKR-360 is a nice combo set, which combing 2.4Ghz RF mini keyboard and MCE Remote Control together.

All of them are based on 2.4Ghz radio frequency, 10-30 meters effective working range and 360 degree navigation, with sleek and elegant design. mini keyboard with trackball remote control, elegant and smart. You don't need to install any driver, it will automatic start all of function when you plug the receiver, It is great device to Media Center PCs, Home Theater PCs, Living Room, or Car PCs or IPTV or IP Settop Box.

You will like this speical mini keyboard with remote combo, there is no cables connected to the keyboard or remote, you can put it away to save spce when you finish using it. it is orgonomically designed allwoing for comfortable use one table or lap. or you can put even on bed or settee when you are lie-in.

TV program, Internet, E-mail, music, all of them, just use a small2.4G wireless remote controller, Integrated with FOCUS 2.4G wireless keyboard, Switch the program or surf the Internet and E-mail, carry on the on-line game or work happily will be more convenience

Please read carefully the information and instructions contained in this manual, and you are sure to obtain a obtain a higher level of computing enjoyment.

Specification

- Compatible with Windows 2000 / Windows XP / Windows Vista / Windows 7.
- Keyboard: (RK-360)
    - 2.4 Ghz radio frequency, 10 meters effective working.
    - 360-degree navigation, sleek and elegant design.
    - 86 keys Mini Keyboard, with 10 Internet / Multimedia hot-keys.
    - Bounce Time: less than 10m sec.
    - Non-skid rubber feet.
    - 2-AA batteries included for up to 3 months use.
    - Dimension: 304 x 151 x 23 mm.
- Remote: (RM-518)
    - 2.4GHz wireless with 8 channels, 360-degree navigation.
    - Working range; 10 meters.
    - Built-in optical trackball, mouse key.
    - Trackball: 19mm optical, 800DPI.
    - Key: Including 45 hot keys & 2 mouse keys & MCE directly keys.
    - 2-AA batteries included for up to 3 months use.
    - Dimension: 178 x 50 x 33 mm.
- Receiver:
    - USB Dongle.
    - Dimension: 78 x 21.5 x 10 mm.
- Patent No.:
    - ZL 2006 2 0002046.8
    - ZL 2007 2 0143404.1
    - M 318157
    - M 296544
    - Nr 20 2006 002 499.9

Installation

1. Turn on the Computer.

2. Plug the USB Receiver of the keyboard unto the USB ports of your computer.

3. Open the battery cover on back of keyboard and Remote control, place AAA batteries inside the battery compartment. Close the battery compartment cover.

Push to open

Push to open

place AAA batteries inside the battery compartment

4. Setting ID

Keyboard Setting:

**a.** Press ID button on the receiver, the LED is on flash which means ID is searching. (Picture A)

ID Button

LED

(Picture A)

b. Press ID button on Back of the keyboard, the LED is off which means setting is successful. (Picture B)

ID Button

(Picture B)

Remote Setting:

a. Open the battery cover.
b. Press ID button on the receiver, the LED is on flash which means ID is searching. (Picture A)
c. Press ID button on the back of remote, the LED on the receiver is off which means setting is successful. (Picture B)

(Picture A)

ID Button

LED

(Picture B)

ID Button

Remarks

1. RF Signal LED on the receiver will flash when the keyboard or remote is being used. (Picture A)
2. When Battery Low LED lights, it means the keyboard or Remote requires changing batteries. (Picture B C)

Receiver(A)	Keyboard(B)	Remote(C)
LED	LED	LED

Keys Description

Keyboard Description

Internet Hot Keys

Application Key

Multimedia Center

Win - Keys

Remote Control Description

Battery Low

4 MCE Hotkeys:
My TV, My Music,
My Picture,
My Video

3 Application Hotkeys:
Close,
Sleep,
MCE Start Key

28 Remote Hotkeys:
Live TV, Recorded TV,
Guide, DVD Menu,
Channel/Page Up,
Channel/Page Down,
Directional 4 keys,
OK, Back,
Info, clear,
Enter, Num Lock,0~9,*,#

Control Cursor with Optical Trackball:
800 DPI Optical Trackball,
Left Click, Right Click

10 Multimedia Hotkeys:
Record, Stop, Play/Pause,
Skip, Rewind,
Next-Track, Pre-Track,
Change Volume, Mute

Important: In order to use My TV, My Video, My Picture, Live TV & Media hotkeys,
Users need to activate the Media Center function first. To activate Media
Center function, simply press the MCE hotkey.

Trouble Shooting:

If your keyboard or remote control can not work after installation, please check followings:

a. Make sure you have connected the receiver correctly to the computer; the receiver has been properly plugged onto computer's USB port.

b. Make sure you have inserted AAA & AA batteries each into keyboard and remote, and they are compartment correctly.

(2 pcs for keyboard,2 pcs for remote)

c. If without any interference, such as other computer peripherals, the working distance (the distance between keyboard and the receiver) is about 10 meters.

Notice:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Important note:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

FCC information:

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication.

However, there is no grantee that interference will not occur in a particular installation. If this equipment dose cause harmful interference to radio or television reception, which can determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.